

---

# **TECHNICAL PROCEDURE**

**For**

**Servicing of Lift Axle Suspension System**

**For Rigid Truck LPT 3118 &**

**LPT 3718 Pusher / Prima 3123.T & Prima 3723.T**




*Information provided in this bulletin is accurate as on the date of publishing. Changes would have been made in the product after the date of this publication. Please get in touch with us for any updates*

---

**TATA AUTOCOMP HENDRICKSON SUSPENSIONS PVT LTD**

Gat No. 431/1, Medankarwadi, Chakan - Alandi Road, Off. Pune - Nashik Highway,  
Near Hotel Gandharwa, PUNE - 410 501 | Tel:+91 2135 670670 | Email: [service@tacohendrickson.com](mailto:service@tacohendrickson.com)





**Technical Procedure**

**Subject : Service Instructions**

**LIT No. : Pusher Axle Suspension**

**Release : 2016 | Revision : 0**

**CONTENT**

| <b>SR. NO.</b> | <b>DESCRIPTION</b>  | <b>PAGE</b> |
|----------------|---|-------------|
| A              | Introduction .....  | 01          |
| B              | Recommended Maintenance schedule .....                          | 03          |
| C              | Dos and Don'ts for driver/operator .....                        | 04          |
| D              | General & Special tools required .....                          | 06          |
| E              | Main Air Spring Service Procedure .....                         | 08          |
| F              | Lift Air Spring Service Procedure .....                         | 10          |
| G              | Rebound Strap Service Procedure .....                           | 12          |
| H              | Wear Pad Service Procedure .....                                | 14          |
| I              | Bushing outer Rubber Service Procedure .....                    | 20          |
| J              | Steering Stabilizer Service Procedure .....                     | 26          |
| K              | Troubleshooting Guide .....                                     | 29          |
| L              | List of Serviceable Child Parts .....                           | 30          |
| M              | GAP Measurement between Axle Seat &<br>External Bump stop ..... | 30          |
| N              | Part No. Cross reference & Torque Values .....                  | 31          |
|                | i) Torque Values 3118/3718 Pusher                               |             |
|                | ii) Torque Values 3123.T/3723.T Prima                           |             |



**A. Introduction**

This publication is to acquaint and assist maintenance personnel in preventive maintenance and rebuild of the PARALIFT suspension system.

THSL reserves the right to make changes and improvements to its products and manuals at any time. Contact THSL Tech Services at +91 2135 670 670 or [service@tacohendrickson.com](mailto:service@tacohendrickson.com) for information on the latest version of this manual.

NOTE

Use only genuine THSL parts for servicing this suspension system. Most THSL parts can be identified by the Hendrickson trademark.

**IMPORTANT SAFETY NOTICE**

Proper maintenance, service and repair is important to the reliable operation of the suspension. The procedures recommended by THSL and described in this technical publication are methods of performing such maintenance, service and repair.

The warnings and cautions should be read carefully to help prevent personal injury and to assure that proper methods are used. Improper servicing may damage the vehicle, cause personal injury, render it unsafe in operation, or void manufacturer's warranty.

Failure to follow the safety precautions in this manual can result in personal injury and/or property damage. Carefully read, understand and follow all safety related information within this publication and on all decals.

**EXPLANATION OF SIGNAL WORDS**

Hazard "Signal Words" (Danger-Warning-Caution) appear in various locations throughout this publication. Information accented by one of these signal words must be observed to help minimize the risk of personal injury to service personnel, or possibility of improper service methods which may damage the vehicle or render it unsafe. Additional Notes or Service Hints are utilized to emphasize areas of procedural importance and provide suggestions for ease of repair. The following definitions indicate the use of these signal words as they appear throughout the publication.

 **DANGER**

INDICATES IMMEDIATE HAZARDS WHICH WILL RESULT IN SEVERE PERSONAL INJURY OR DEATH.

 **WARNING**

INDICATES HAZARDS OR UNSAFE PRACTICES WHICH COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.

 **CAUTION**

INDICATES HAZARDS OR UNSAFE PRACTICES WHICH COULD RESULT IN DAMAGE TO MACHINE OR MINOR PERSONAL INJURY.

NOTE

An operating procedure, practice condition, etc. which is essential to emphasize.

SERVICE HINT

A helpful suggestion which will make the servicing being performed a little easier and/or faster.

**WARNINGS AND CAUTIONS**

There are various warnings and cautions that should be read carefully to minimize the risk of personal injury and to assure that proper methods are used. Improper servicing may damage the vehicle or render it unsafe in operation.

**! WARNING**

**LOAD CAPACITY**

THSL REMINDS USERS TO ADHERE TO THE PUBLISHED CAPACITY RATINGS FOR THE SUSPENSIONS. ADD-ON AXLE ATTACHMENTS AND OTHER LOAD TRANSFERRING DEVICES CAN INCREASE THE SUSPENSION LOAD ABOVE THE RATED AND APPROVED CAPACITIES WHICH COULD RESULT IN FAILURE AND LOSS OF VEHICLE CONTROL, POSSIBLY CAUSING PERSONAL INJURY OR PROPERTY DAMAGE.

**! WARNING**

**MODIFYING COMPONENTS**

DO NOT MODIFY OR REWORK PARTS. DO NOT USE SUBSTITUTE PARTS OF THE SUSPENSION. USE OF A MODIFIED OR REPLACEMENT PARTS NOT AUTHORIZED BY THSL MAY NOT MEET THSL SPECIFICATIONS, AND CAN RESULT IN FAILURE OF THE PART, LOSS OF VEHICLE CONTROL, AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE. USE ONLY THSL AUTHORIZED REPLACEMENT PARTS DO NOT MODIFY PARTS WITHOUT AUTHORIZATION FROM THSL.

**! WARNING**

**TORCH/WELDING**

DO NOT USE A CUTTING TORCH TO REMOVE ANY ATTACHING FASTENERS. THE USE OF HEAT ON SUSPENSION COMPONENTS WILL ADVERSELY AFFECT THE STRENGTH OF THESE PARTS. A COMPONENT DAMAGED IN THIS MANNER CAN RESULT IN THE LOSS OF VEHICLE CONTROL AND POSSIBLE PERSONAL INJURY OR PROPERTY DAMAGE.

**! CAUTION**

**PROCEDURES AND TOOLS**

A MECHANIC USING A SERVICE PROCEDURE OR TOOL WHICH HAS NOT BEEN RECOMMENDED BY THSL MUST FIRST SATISFY HIMSELF THAT NEITHER HIS SAFETY NOR THE VEHICLE'S SAFETY WILL BE JEOPARDIZED BY THE METHOD OR TOOL SELECTED. INDIVIDUALS DEVIATING IN ANY MANNER FROM THE INSTRUCTIONS PROVIDED ASSUME ALL RISKS OF CONSEQUENTIAL PERSONAL INJURY OR DAMAGE TO EQUIPMENT INVOLVED.


**! WARNING**

**PERSONNEL PROTECTIVE EQUIPMENT**

ALWAYS WEAR PROPER EYE PROTECTION AND OTHER REQUIRED PERSONAL PROTECTIVE EQUIPMENT TO HELP PREVENT PERSONAL INJURY WHEN YOU PERFORM VEHICLE MAINTENANCE, REPAIR OR SERVICE.

**Know the system  
Para lift Suspension -**

**Fig 1.1: Paralift Suspension System PH-3 Suitable for LPT 3118 & LPT 3718 Pusher / Prima 3123.T & Prime 3723.T**



**B - Recommended Maintenance Schedule**
**Table 2.1**

| SI | Component           | Parameter to be checked   | Interval   | Activity   |
|----|---------------------|---|--|--|
| 1  | Main Air Spring     | Main Air Spring Height<br>T250 ± 25mm (in Lift Axle Deployed condition) | During regular service interval  | Refer TML Operator Service Book for more details   |
|    |                     | Leakage   | Regularly  | Check for air leakage  |
| 2  | Lift Air Spring     | Leakage   | Regularly  | Check for leakage  |
| 3  | Steering Stabilizer | Leakage   | Regularly  | <ul style="list-style-type: none"> <li>• Check for leakage / structural damage</li> <li>• Check wheel cut angles and position of wheel cut stopper as mentioned in TML Vehicle Manual</li> </ul>   |
| 4  | Rebound strap       | Broken  | Regularly  | Replace it if found cut or damaged   |
| 5  | Wear Pad            | Damage / wear   | As required  | <ul style="list-style-type: none"> <li>• Replace it, if found damaged / worn out.</li> <li>• Replace whenever adjacent parts like bush being replaced.</li> </ul>  |
| 6  | Beam Bushes         | Damage / wear   | Check whenever Beams are disassembled for repair or service.           | Replace if found damaged or worn out   |
| 7  | M27 Fastener        | Torque Value  | First service at 40000 km and the next every service interval of Truck | Verify torque and if necessary Re-torque by applying specified torque.<br>*Refer Section N for Torque values   |
| 8  | Pneumatic System    | Functioning   | During regular service interval  | a. In Fully Laden condition (at specified GVW) lift axle should be lowered<br>b. Lift axle should be lifted automatically when the reverse gear is engaged<br>c. Lift Axle should be lowered automatically when the ignition is switched off |
| 9  | External Bump Stop  | Gap measurement   | During regular service interval  | *Refer Section - M for details   |

**Note:**









1. Stop & turn off the vehicle before servicing lift axle
2. Do avail the services of workshop authorized by OEM for servicing pneumatic circuits. Component damage, loss of vehicle control might occur if there is any incorrect correction or alteration.
3. Use only TATA / THSL Genuine parts for lift axle components/parts/sub-assemblies/Fastener

**C - DOs and DON'Ts for driver / operator with lift axle fitted vehicle.**

**Do's and Don't's**

Table 3.1

**! WARNING**

| Sr. No. | Do's and Dont's   | Photo  |
|---------|---|--|
| 1       | <p>Ensure air supply to air spring is disconnected while working on air spring or related components.</p> <p><b>Sudden release of high pressure air can lead to body injuries.</b></p>  |   |
| 2       | <p>While working on structural components involving high torques, ensure that all personnel are at safe distance and torque wrench grip is firm.</p> <p><b>Torque wrench slippage could cause fatal injury.</b></p>                                 |   |
| 3       | <p>Allow sufficient clearance around the air spring else, air spring would weaken if metal parts continuously rub with it.</p> <p><b>Weak air spring would fail soon.</b></p>   |    |
| 4       | <p>Use only THSL or TML supplied components/parts/ subassemblies/ fasteners for replacements. Substandard fasteners cannot retain torque for long and work loose.</p> <p><b>Loose bolts make holes oblong and lead to consequential damages</b></p> |   |
| 5       | <p>Use only THSL or TML supplied components / parts</p> <p><b>Spurious parts may fail instantly during installation and lead to consequential damages</b></p>   |   |
| 6       | <p>Suspension should be greased regularly as per the recommended maintenance schedule.</p> <p><b>Stub axle cannot move freely around king pin due to less or no grease and thus stabilizer can fail prematurely.</b></p>                            |   |
| 7       | <p>Air springs and bushes should be protected from exposure to chemicals. They should be covered properly while other works are in progress</p> <p><b>Such exposure would reduce life of air spring and bushes</b></p>                              |   |

**! WARNING**

**! CAUTION**

**! CAUTION**

**! CAUTION**

**! CAUTION**

**! CAUTION**



Do's and Don't's

 CAUTION

 CAUTION








 CAUTION

 CAUTION

 CAUTION

 CAUTION

 CAUTION

| Sr. No. | Do's and Don't's   | Photo   |
|---------|--|---|
| 8       | Do not use damaged or deflated tyre on the axle.<br><b><i>It leads to premature failure of main air spring due to over extension</i></b>   |    |
| 9       | Don't alter vehicle height by adding extra leaves/removing leaves from suspension or by any other means.<br><b><i>It leads to early failure of main air spring due to over extension.</i></b>  |    |
| 10      | Don't tamper structural components by drilling holes or any structural alteration.<br><b><i>Alteration would weaken the structural parts and can lead to premature failure</i></b>   |   |
| 11      | Do not add spacer below axle seat.<br><b><i>Spacer addition would damage Stabilizer and leads to premature failure</i></b>   |   |
| 12      | Don't alter the pneumatic circuit or valves provided by OEM.<br><b><i>Such changes leads to malfunctioning of lifting system and would damage the components.</i></b>  |  |
| 13      | Don't alter the Electrical circuit of solenoid valve provided by OEM. Do not shift the solenoid valve into the driver's cabin for deploying the system when needed.<br><b><i>Lowering the axle while vehicle is in motion would damage the components and can be dangerous at times.</i></b> |   |
| 14      | Axle should be lifted as soon as reverse gear is engaged. Vehicle should be driven in reverse direction only after the axle is lifted completely.<br><b><i>Else stabilizer would fail prematurely.</i></b>   |  |

**D - General & Special Tools required**

**General Tools :-**

**Table 4.1**

| S. No | Fastener size | Spanner & Socket Size | Torque Values |
|-------|---------------|-----------------------|---------------|
| 1     | M10           | No. 17                | 20Nm          |
| 2     | M12           | No. 19                | 40Nm          |
| 3     | M16           | No. 24                | 250Nm         |
| 4     | M18           | No. 27                | 280Nm         |
| 5     | M20X1.5       | No. 30                | 60Nm          |
| 6     | M20X2.5       | No. 30                | 370Nm         |
| 7     | M27           | No. 41                | 1200Nm        |

**Table 4.2**

| SI | Tools Type           | Size / No.  |
|----|----------------------|---|
| 1  | Open spanner size    | 17, 19, 20, 22, 24, 27, 30, 32, 34, 37, 41                  |
| 2  | Ring spanner size    | 17, 19, 20, 22, 24, 27, 30, 32, 34, 37, 41                  |
| 3  | Socket size          | 17, 19, 20, 22, 24, 27, 30, 32, 34, 37, 41 (1" sqdr socket) |
| 4  | Deep socket size     | 17, 19, 20, 22, 24, 27, 30, 32, 34, 37, 41 (1" sqdr socket) |
| 5  | Extension for socket | 5" long and 10" long  |
| 6  | Connector            | 1" (F) x 1" (M) connector                                   |
| 7  | Plier                | Combination plier   |
| 8  | Hammer               | Ball pin hammer   |
| 9  | Mallet               | Standard mallet   |
| 10 | Jack                 | Hydraulic Jack of capacity up to 20T                        |
| 11 | Air pipe hose        | Air Pipe hose suitable for pneumatic nut runner             |
| 12 | Pneumatic runner     | Pneumatic Nut runner  |
| 13 | Torque wrench        | 50Nm, 275Nm, 370Nm, 550Nm, 940Nm, 1200Nm                    |

**Special Tools :**

**Table 4.3**

| SI | Description                   | Remarks   |
|----|-------------------------------|---|
| 1  | Stabilizer Compress Fixture   | Stabilizer assembly on axle - Refer Below           |
| 2  | Loctite 270                   | Liquid Loctite for Re tightening of M27 Pivot bolts |
| 3  | Pressure Gauge with Connector | Main Air spring Pressure Measurement                |

**Details of Special Tools**

**1. Stabilizer compressor fixture -**

Install stabilizer inside the special tool, this helps to fit the stabilizer in a safer way.



Fig. 4.1: Stabilizer compressor fixture



Fig. 4.2: Stabilizer fitted into the fixture

**2. Pressure Gauge with Connector -**

Main Air Spring Pressure measurement



Connect to Main air spring input side

Connect pressure gauge

Connect the main supply pipe, which is coming from LACV



Fig. 4.4: Air Pressure Gauge

Fig. 4.3:  
Adopter Female Size - 14 mm  
Adopter Male size - 14 mm

**STEP 1**

Remove air Connection of Main Air Spring & Insert Adapter in its place



Fig. 4.5



Fig. 4.6

**STEP 2**

Fit the main air spring original male connector inside adapter



Fig. 4.7



Fig. 4.8

**STEP 3**

Connect the pressure gauge



Fig. 4.9

**STEP 4**

The pressure in main air spring must be  $5.6 \pm 0.2$  bar



Fig. 4.10

**E - Main Air Spring Assembly Procedure**







**Preparation :-**

- Park the vehicle on pit/ ramp/ Plain Surface.
- Apply parking brakes.
- Remove air completely from the air tank & air springs.
- Ensure Genuine Fasteners are not used more than 3 times otherwise replace fasteners with new Genuine Fasteners.
- Ensure lift axle should be in deployed position

**General Instruction :-**

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.
- Ensure specific instructions to be followed for truck and prima segment as below

Table 5.1







| <b>E. Removal of Main Air Spring</b> |   |  |  |
|--------------------------------------|---|--|--|
| SI                                   | Activity  | LPT 3118 (Ph-3) & 3718 Pusher  | Prima 3123.T & 3723.T  |
| E1                                   | Removal of Main Spring Air connection                   |   |                  |
| E2a                                  | Remove mounting Flange Hex Head Nuts on Main air spring |  |                 |
| E2b                                  | Remove HD M10 bolts at the axle seat                    |  | <br>M10 HD Bolt |

**Removal of Main Air Spring**

| SI  | Activity   | LPT 3118 (Ph-3) & 3718 Pusher  | Prima 3123.T & 3723.T |
|-----|--|--|-----------------------|
| E2c | Press the Main air Spring by hand to remove stud from Upper Air spring mounting plate and remove it. |  |                       |

Table 5.2

**E3. Assemble New Main Air Spring**

|     |  |  |   |
|-----|--|--|---|
| E3a | Press the air spring, fit between air spring mounting and axle seat top plate. |    |   |
| E3b | Insert Air spring studs in upper air spring mounting plate holes               |   |   |
| E3c | Insert M20 and M12 nut and torque it   |  <p>M12 Flange hex nut</p> <p>M20 Flange hex nut and tight</p> |   |
| E3d | Align Holes of Main Air Spring with axle seat, to insert M10 flange head bolt  |  <p>M10 Flange HD, Bolt</p>                                    |   |
| E3e | Tighten the M10 flange head bolt   | Please avoid using pneumatic nut runner while tightening the air spring M10 flange bolts as it will lead to over tightening of the bolts.          |   |
| E4  | Pneumatic Connection to Main Air Spring  | LPT 3118 (Ph-3) & 3718 Pusher  | Prima 3123.T & 3723.T   |
|     |  |    |  |

**Note:**

- 1) Follow similar Procedure for the Main air spring on the other side.
- 2) Please use preset torque wrenches for tightening.
- 3) For Fastener Torque values refer Section - N.

**F - Lift Air Spring Assembly Procedure**

**Main Instruction:-**

- Park the vehicle on pit/ramp/Plain Surface.
- Apply parking brakes.
- Remove air completely from the air tank & air springs.
- Ensure Genuine Fasteners are not used more than 3 times otherwise replace fasteners with new Genuine Fasteners.

**General Instruction:-**

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.

**STEP - F1. Remove Air Connection from Lift Air Spring**

Remove air connection from Lift air spring



Fig. 6.1

**STEP - F2. Remove mounting nuts on Lift Air Spring**

Remove mounting nut and bolts of lift air spring



Fig. 6.2

**STEP - F3. Remove old lift air spring**

- Press the lift air spring to remove stud from beam assembly and remove it.



Fig. 6.3

**STEP - F4. Assemble New Lift air spring**

- Press the new air spring & insert between beam arms



Fig. 6.4

**STEP - F5. Tight mounting & air connection Nuts**

- Insert M10 flange Bolt sand M20 Flange Hex nut.
- For Fastener Torque values refer Section - N.

M10 Flange Bolts



Fig. 6.5

M20 flange Nut




Fig. 6.6

**STEP - F6. Air Connection to Lift Air Spring**



Connect with  
Pneumatic hose

Fig. 6.7

**Note:**

- Similar Procedure to be followed for the Lift air spring on the other side.
- For Fastener Torque values refer Section - N.

**G - Rebound Strap Service Procedure**

**Main Instruction:-**


- Park the vehicle on pit / ramp / Plain surface.
- Apply parking brakes.
- Remove air completely from the air tank & air springs.
- Ensure genuine fasteners are not used more than 3 times otherwise replace fasteners with new genuine fasteners
- Place jack under the Beam axle, to the side where the replacement of rebound strap to be carried out.

**General Instruction:-**

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.


**STEP - G1. Remove Rebound Clip on Axle Seat and Chassis**

Remove All M16 nut, Flange bolt and washer from the Chassis



Remove All M16 nut, Flange bolt and washer from the Chassis

Fig. 7.1



Remove All M16 nut, Flange Bolt. Remove Rebound Clip from Axle Seat and Chassis Bolt and washer on Axle Seat.

Fig. 7.2

**STEP - G2. Remove Rebound Clip from Rebound Strap**

Remove both Rebound Clips from Rebound Strap and Replace the Rebound Strap with Genuine Rebound strap.




Fig. 7.4

Fig. 7.3



**STEP - G3 Fit Rebound Clips on Chassis and Axle Seat**

Visually match all Rebound Clip holes with frame holes and Axle Seat holes.




Fig. 7.5



Fig. 7.6

**Note :**

- Similar Procedure for other side Rebound Straps
- For Fastener Torque values refer Section - N.

**H - Wear Pad Service Procedure**

**Images of Wear Pad Wear / Missing in field**



Fig. 8.1 - Correct (Wear Pad Visible)



Fig. 8.2 - Incorrect (Wear Pad Missing)

**Main Instruction:-**

- Park the vehicle on pit/ramp/Plain Surface.
- Apply parking brakes.
- Remove air completely from the air tank & air springs.
- Ensure Genuine Fasteners are not used more than 3 times otherwise replace fasteners with new Genuine Fasteners.

**General Instruction:-**

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.

**STEP - H1a. Remove air connection from Lift Air Spring**



Fig. 8.3

Remove air connection from Lift air spring

**STEP - H1b. Remove air connection from Main Air Spring**

**LPT 3118 & 3718 Pusher**



Fig. 8.4

Remove air connection

**Prima 3123.T & 3723.T**



Fig. 8.5

**STEP - H1c. Remove mounting nut and bolts on Lift Air Spring**

Remove mounting nut and bolts on lift air spring



Fig. 8.6

**STEP - H2. Loosen Z section from Hanger**

Ensure applying of rigid stand beneath axle such that the axle load will be taken by the stands

Loosen All M16 flange Head Bolt, nut




Fig. 8.7

**STEP - H3. Remove Bottom Beam Assembly and Wear Pad**

- Remove both side M27 Hex Head Bolt, Nut and washer
- Remove bottom beam assembly with old wear pads.

Remove both side M27 Hex Head Bolt, Nut and washer




Fig. 8.8

Remove bottom beam assembly and old wear pad

**STEP - H4. Remove Top Beam Assembly and Wear Pad**

- Remove both side M27 Hex Head Bolt, Nut and washer
- Remove M16 Hex Head Bolt, Nut and washer and dis assemble the Rebound clip
- Remove old top Beam assembly with old wear pads

1) Remove both side M27 Hex Head Bolt, Nut and washer





Fig. 8.9



2) Remove M16 Bolt, Nut and washer and dis assemble the Rebound clip

Fig. 8.10

3) Remove top Beam assembly and old wear pad




Fig. 8.11

**STEP - H5a. Fit Top Beam Assembly with New Wear Pad**

First Assemble Top Beam assembly then Bottom beam assembly






Fig. 8.12

Put Top Beam Assembly with new wear pad

**STEP - H5b. Tight Nuts, Bolt and Washer**

- Apply Loctite 270 (i.e. liquid Loctite 2-3 drops) to the threads of M27 bolts before tightening.
- Assemble the Rebound clip and tighten the M16 bolts, nuts and Washer.
- For Fastener Torque values refer Section - N.



**STEP - H6a. Fit Bottom Beam Assembly with New Wear Pad**



**STEP - H6b. Tighten M27 Nuts, Bolt and Washer**

- Apply Loctite 270 (i.e. liquid Loctite 2 to 3drops) to the threads of M27 bolts before tightening.
- For Fastener Torque values refer Section - N. (For latest updates, refer latest released service circular)

Put bottom beam Assembly with new wear pads



Fig. 8.16

Aligned holes and insert M27 Hex Head Bolts, nuts and washer




Fig. 8.17

Tight M27 Hex Head bolts, nuts and washer

**STEP H7. Ensure the Placement of Wear Pad**



Fig. 8.18

New wear pad at hanger side



Fig. 8.19

New wear pad at Axle Seat side

**STEP H8. Assemble Lift Air Spring**

- Tighten M10 Flange HD bolts and M20 Flange
- For Fastener Torque values refer Section - N.  
(For latest updates, refer latest released service circular)

Press the lift air spring & insert Between beam arms



Fig. 8.20


Tighten M10 Flange HD bolts and M20 Flange Hex Head Nut and Connect with air hose



Fig. 8.21

**STEP - H9. Tighten Z Section Bolts**

- Tighten M16 Flange Head bolt, nuts and washer as per specified torque
- For Fastener Torque values refer Section - N.  
(For latest updates, refer latest released service circular)



Tighten M16 Flange Head bolt, nuts and washer as per specified torque

Fig. 8.22




Fig. 8.23

**Note :**

- Similar Procedure for other side Wear Pad.
- For Fastener Torque values refer Section - N. (For latest updates, refer THSL drawing 01AX081Z00/01AX041Z00 with latest issue level)

## I - Bushing outer Rubber Service Procedure

### Main Instruction:-

- Park the vehicle on pit/ramp/Plain Surface.
- Apply parking brakes.
- Remove air completely from the air tank & air springs.
- Ensure Genuine Fasteners are not used more than 3 times otherwise replace fasteners with new Genuine Fasteners.

### General Instruction:-

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.

### STEP - I1a. Remove air connection from Lift Air Spring



Remove air connection from Lift air spring

Fig. 9.1

### STEP - I1b. Remove air connection from Main Air Spring

#### LPT 3118 & 3718 Pusher



Fig. 9.2

Remove air connection

#### Prima 3123.T & 3723.T




Fig. 9.3

### STEP - I1.c. Remove mounting nut and bolts on Lift Air Spring



Remove mounting nut and bolts on lift air spring

Fig. 9.4



**STEP - I2c Loosen Z section from Hanger**

Ensure applying of rigid stand beneath axle such that the axle load will be taken by the stands

Loosen All M16 flange Head Bolt, nut




Fig. 9.5

**STEP - I3. Remove Bottom Beam Assembly and Wear Pad**

- Remove both side M27 Hex Head Bolt, Nut and washer
- Remove bottom beam assembly with old wear pads.

Remove both side M27 Hex Head Bolt, Nut and washer




Fig. 9.6

**STEP - I4. Remove Top Beam Assembly and Wear Pad**

- Remove both side M27 Hex Head Bolt, Nut and washer
- Remove M16 Hex Head Bolt, Nut and washer and dis assemble the Rebound clip
- Remove old top Beam assembly with old wear pads

1. Remove both side M27 Hex Head Bolt, Nut and washer Remove bottom beam assembly and old wear pad




Fig. 9.7

2. Remove M16 Bolt, Nut and washer and dis assemble the Rebound clip



Fig. 9.8




**Step 15. Remove Inner metal sleeves from beam assembly**



Remove the Inner metal sleeve from beam assembly

**Step 16. Remove rubber bushes from beam assembly**



Remove the rubber bushes from beam assembly

**Step 17. Insert new rubber bushes into the tube of beam assembly**






Fig. 9.13 Check the height of rubber bush face to beam tube face within 4.5 to 6.5 mm

**Step 18. Insert Inner metal sleeve into rubber bushes**



Fig. 9.14 Insert Inner metal sleeve into rubber bushes

**STEP - 19.a. Fit Top Beam Assembly with New Wear Pad**

First Assemble Top Beam assembly then Bottom beam assembly



Fig. 9.15 Put Top Beam Assembly with new wear pad

**STEP - 19.b. Tight Nuts, Bolt and Washer**

- Apply Loctite 270 (i.e. liquid Loctite 2-3 drops) to the threads of M27 bolts before tightening.
- Assemble the Rebound clip and tighten the M16 bolts, nuts and Washer.
- For Fastener Torque values refer Section - N




Fig. 9.16

Assemble the Rebound clip and tighten the M16 bolts, nuts and washers




Fig. 9.17

3. Tight M27 Hex Head bolts, nuts and washer

**STEP - I10.a. Fit Bottom Beam Assembly with New Wear Pad**




Fig. 9.18

Put Bottom Beam Assembly with new wear pad

**STEP - I10.b. Tighten M27 Nuts, Bolt and Washer**

- Apply Loctite 270(i.e. liquid Loctite 2 to 3drops) to the threads of M27 bolts before tightening.
- For Fastener Torque values refer Section - N.

Put bottom beam Assembly with new wear pads




Fig. 9.19

Aligned holes and insert M27 Hex Head Bolts, nuts and washer




Fig. 9.21

Tight M27 Hex Head bolts, nuts and washer

**STEP - I11. Ensure the Placement of Wear Pad**



Fig. 9.22

New wear pad at hanger side



Fig. 9.23

New wear pad at Axle Seat side

**STEP - I12. Assemble Lift Air Spring**

- For Fastener Torque values refer Section - N. (For latest updates, refer THSL drawing no.01AX081Z00/01AX041Z00 with latest issue level)

Press the lift air spring & insert M20 Flange Between beam arms



Fig. 9.24

Tighten M10 Flange HD bolts and Hex Head Nut and Connect with air hose



Fig. 9.25

## STEP - I13. Tighten Z Section Bolts




Fig. 9.26




Fig. 9.27

Tighten M16 Flange Head bolt, nuts and washer as per specified torque

### Note:

- Similar Procedure for other side to replace Beam bushes
- For Fastener Torque values refer Section - N

## J - Steering Stabilizer Service Procedure

### Main Instruction:-

- Park the vehicle on pit / ramp / Plain Surface.
- Apply parking brakes.
- Remove air completely from the air tank & air springs.
- Ensure Genuine Fasteners are not used more than 3 times otherwise replace fasteners with new Genuine Fasteners.
- Ensure applying of rigid stand beneath axle such that the axle load will be taken by the stands.


### General Instruction:-

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.

**General Instruction:-**

- Ensure that chamfered side of washer is towards Nut (or bolt) and flat side rests on the component face.
- Ensure that flat side of Nut rests on washer.

**STEP - J1. Place the fixture on to the stabilizer neck**




Put Stabilizer Fixture on stabilizer neck

Fig. 10.1

**STEP - J2. Remove old Stabilizer**

Put Stabilizer Fixture on stabilizer necks on both side then Loose M18 Nuts and Remove Stabilizer



Remove M18 Flange Head Bolt and nut

Fig. 10.2



Remove Old Stabilizer

**STEP - J3a. Fit New Stabilizer**




Fig. 10.3

New Stabilizer press in stabilizer fixture

**STEP - J3b. Align Holes & Insert M18 Flange bolts**




Fig. 10.4

**STEP - J3c. Tighten M18 Nuts as per Specified Torque**

- Tighten M18 Flange bolt and nut/washer then remove stabilizer fixture.
- For Fastener Torque values refer Section - N



Fig. 10.5




Fig. 10.6

**Note:**

- Please ensure that M18 bolt length should be 100mm at axle
- Similar Procedure for other side Stabilizer.
- For Fastener Torque values refer Section - N



**K - Troubleshooting Guide**

**Trouble shooting of Lift axle related issues**

Table 11.1

| SL. No | Problem  | Possible cause  | Possible solution   |
|--------|--|---|---|
| 1      | Lift axle not in contact with the ground even in laden condition   | Insufficient air pressure to Main air spring  | Inspect the pneumatic circuit   |
| 2      | Insufficient air pressure to the system  | Defect in air compressor  | Inspect the pneumatic circuit   |
|        |  | Valve leakage/damage  | Replace / repair valve  |
|        |  | Damaged hose  | Replace hose  |
| 3      | Lift Axle not lifted to the standard position<br>- For laden - 125mm<br>- For unladen - 150mm<br><br>From the ground till bottom of the tire | Insufficient air pressure to Lift air spring  | 1. Check system pressure.<br>2. Inspect air circuit<br>3. Check pneumatic pressure at lift air spring   |
|        |  | Interference with Chassis, drive line or other components   | Inspect for interference and rectify  |
|        |  | Unit not installed properly   | Check installation with factory installation drawing  |
| 4      | Lift axle jump (Vertically)  | Insufficient air pressure to Main air spring  | Inspect the pneumatic circuit   |
|        |  | Unbalanced Wheel  | Balance Wheel   |
| 5      | Axle doesn't track forward   | Hanger bracket mounted incorrectly on chassis frame   | Remount correctly   |
| 6      | Stabilizer bent or broken  | Wheel cut stopper bend/ broken/worn out   | Replace it  |
|        |  | Axle extension portion worn out   | Repair or replace   |
| 7      | Lift axle Wheel wobbling   | <ul style="list-style-type: none"> <li>• Less pressure in main air spring i.e., below 5.6 bar</li> <li>• Bolt Loosening</li> <li>• Hole oblong</li> <li>• Wear out of beam bushes</li> <li>• Improper Wheel alignment &amp; wheel balancing.</li> </ul> | <ul style="list-style-type: none"> <li>• Check pneumatic pressure at main air spring and adjust it</li> <li>• Check all fasteners especially M16 Flange bolts of Z section &amp; M27 Pivot Bolts for bolt loosening, if found loose tighten</li> <li>• Check for M27 Bolt Hole Oblong.</li> <li>• Check for Wear out of beam bushes, Replace if found damaged or worn out</li> <li>• Check for proper Wheel alignment &amp; wheel balancing.</li> </ul> |

**L - List of serviceable child parts**

Table 12.1

| SL. No.   | List of serviceable parts | THSL Part Nos. | TML Part Nos.   |
|---|---------------------------|----------------|---|
| 1   | Bush outer rubber         | 86CX037C01     | 2846 3390 34 09   |
| 2   | Bushing Inner steel       | 86CX038C01     | 2846 3390 34 11   |
| 3   | Wear pad                  | 95CX217C01     | 2846 3390 99 31   |
| 4   | Lift Air springs          | 41CX008C01     | 2846 3390 99 34 or<br>2846 3390 99 56 or<br>2846 3390 99 73 |
| 5   | Main Air Springs          | 41CX014C01     | 2846 3390 99 72 or 2846 3390 99 73                          |
| 6   | Stabilizers               | 44AX007C01     | 2846 3390 99 37 or 2846 3390 99 53                          |
| 7   | Rebound Strap             | 86CX049C01     | 5043 3390 33 07   |
| For Part Nos. related to fasteners please refer Section - N |                           |                |   |

**M - GAP Measurement between Axle Seat & External Bump stop**

Axle Seat Top plate to External Bump Stop Gap in Lift Condition.  
Normal Operating Range 5mm to 10mm




Fig. 13.1

**N. Part No. Cross reference & Torque Values**

**i) Torque Values 3118 / 3718 Pusher**





Table 14.1

| ITEM NO. | THSL PART NUMBER | TML PART NUMBER   | DESCRIPTION                       | QTY. |
|----------|------------------|---|-----------------------------------|------|
| 1        | 10CLD31C01       | 5043 3390 33 08N  | HANGER LH                         | 1    |
| 2        | 10CR031C01       | 5043 3390 33 09N  | HANGER RH                         | 1    |
| 3        | 95CX246C01       | 5043 3390 33 06N  | U SECTION                         | 2    |
| 4        | 51CX021C01       | 2846 3390 02 25   | Z SECTION                         | 1    |
| 5        | 31AL136C01       | 2846 3390 03 39N  | AXLE SEAT LH                      | 1    |
| 6        | 31AR136C01       | 2846 3390 02 92N  | AXLE SEAT RH                      | 1    |
| 7        | 24AL028C01       | 2846 3390 02 93N  | BEAM ASSEMBLY LH                  | 2    |
| 8        | 24AR028C01       | 2846 3390 02 94N  | BEAM ASSEMBLY RH                  | 2    |
| 9        | 95CX217C01       | 2846 3390 99 31   | WEAR PAD                          | 16   |
| 10       | 41CX008C01       | 2846 3390 99 34 OR<br>2846 3390 99 56 OR<br>2846 3390 99 58 | LIFT AIRSPRING                    | 2    |
| 11       | 41CX014Z00       | 2846 3390 99 72N OR<br>2846 3390 99 73N                     | MAIN AIR SPRING                   | 2    |
| 12       | 44AX007Z00       | 2846 3390 99 37 OR<br>2846 3390 99 53                       | STABILIZER<br>(STEERING DAMPER)   | 2    |
| 13       | 11AL046Z00       | 2846 3390 02 95   | AIR SPRING MTG LH                 | 1    |
| 14       | 11AR046Z00       | 2846 3390 02 91N  | AIR SPRING MTG RH                 | 1    |
| 15       | 32AL011Z00       | 2846 3390 02 97N  | EXTERNAL BUMP<br>STOP ASSEMBLY LH | 1    |
| 16       | 86CX049Z00       | 5043 3390 77 01   | REBOUND STRAP                     | 2    |
| 17       | 32CX031Z00       | 5043 3390 33 07   | REBOUND CLIP FINISHED             | 4    |
| 18       | 32AR011Z00       | 2846 3390 02 98N  | EXTERNAL BUMP STOP<br>ASSEMBLY RH | 1    |



Scope of Supply - THSL

Table 14.2

| ITEM NO. | THSL PART NUMBER | TML PART NUMBER | DESCRIPTION   | QTY. |
|----------|------------------|-----------------|---|------|
| 19       | 93CX007C01       | 2846 3390 3359N | M20 x 1.5 (CLASS 10, FLANGE HEX HEAD NUT)   | 2    |
| 20       | 90CX010C01       | 2846 3390 3363N | M16 x 2 x 80LG GRD. 10.9 FLANGE HD. BOLT  | 8    |
| 21       | 92CX102C01       | 2846 3390 3357N | M16 x 2 (GRD 10.0 ALL METAL PREVAILING TORQUE NUT)  | 12   |
| 22       | 90CX034C01       | 2846 3390 3362N | M10 x 1.5 x 25 LG (GRD. 8.8 FLANGE HD. BOLT) OR M10 x 1.5 x 25 LG (GRD. 10.9 FLANGE HD. BOLT) | 4    |
| 23       | 91CX129C01       | 5039 3390 3367N | M27x3x200LG GRD 10.9 HEX HD BOLT  | 4    |
| 24       | 91CX130C01       | 5039 3390 3368N | M27x3x210LG GRD 10.9 HEX HD BOLT  | 4    |
| 25       | 92CX113C01       | 5039 3390 3361N | M27 x 3 (GRD 10.0 HEX NUT)  | 8    |
| 28       | 94CX101C01       | 5039 3390 3315N | M27 HARDENED WASHER   | 16   |
| 27       | 94CX104C01       | 2846 3390 3312N | M16 HARDENED WASHER   | 16   |
| 46       | 91CX126C01       | 11064018820N    | M16X2.0X70Lg GRD 10.9 HEX HD BOLT   | 4    |

Scope of Supply - TML

Table 14.3

| ITEM NO. | TML PART NUMBER  | DESCRIPTION                                | QTY. |
|----------|------------------|--|------|
| 28       | 2846 3390 3318N  | M20 HARDENED PLAIN WASHER                  | 8    |
| 29       | 12460501057N     | BRIGHT WASHER 10.5 IS2016 ST S88451-3C     | 4    |
| 30       | 2846 3390 3363N  | M16X2.0X60 LG.-FLANGE BOLT -10.9           | 26   |
| 31       | 5011 3240 65 03N | HEX FLANGE NUT (SELF LOCKING) M16X2 10.9   | 28   |
| 32       | 5008 3240 3213N  | HEX FL BOLT M16X2X70                       | 4    |
| 33       | 2846 3390 3362N  | M10X1.5X25 LG.-FLANGE BOLT -10.9           | 4    |
| 34       | 2846 3390 3364N  | M18X2.5X130 LG.-FLANGE BOLT -10.9          | 2    |
| 35       | 5009 3240 32 05N | HEX FL BOLT M18X2.5X100                    | 2    |
| 36       | 2846 3390 3358N  | M18X2.5 - AMPT NUT-10                      | 4    |
| 37       | 2846 3390 3335N  | M18-HARDENED PLAIN WASHER                  | 4    |
| 38       | 1107 1712 551N   | HEX FL BOLT M12X55TS17130 10.9S88451-8CH   | 2    |
| 39       | 11071510559N     | HEX FL BOLT M10X55 TS17130-8.8-SS88451S2-Y | 4    |
| 40       | 2846 3390 3360N  | M20X2.5-AMPT NUT-10                        | 8    |
| 41       | 12051598073N     | HEX NUT M10 IS1364P3-8-SS88451-8C          | 4    |
| 42       | 2846 3390 3356N  | M12X1.75 - FLANGE HEX NUT-10               | 2    |
| 43       | 2846 3390 3365   | M20X2.5X75 LG.-FLANGE BOLT -10.9           | 8    |
| 44       | 2846 3390 3359N  | M20X1.5-FLANGE HEX NUT-10                  | 2    |
| 45       | 1214 340 1209N   | HEX FL NUT M12X1.5 ISO 12128 10 S88451-8CH | 2    |
| 48       | 2846 3390 3312N  | M16 HARDENED PLAIN WASHER                  | 4    |
| 47       | 2846 3390 3357N  | M16X2-AMPT NUT-10                          | 4    |

**N. Part No. Cross reference & Torque Values**  
**ii) Torque Values 3123.T/3723.T Prima**




Table 14.4

| ITEM NO. | PART NUMBER | TML Part Number  | DESCRIPTION                       | QTY. |
|----------|-------------|--|-----------------------------------|------|
| 1        | 10CL031C01  | 5043 3390 33 08N   | HANGER LH                         | 1    |
| 2        | 10CR031C01  | 5043 3390 33 09N   | HANGER RH                         | 1    |
| 3        | 95CX246C01  | 5043 3390 33 06N   | U SECTION                         | 2    |
| 4        | 51CX021C01  | 2846 3390 02 25  | Z SECTION                         | 1    |
| 5        | 31AL136C01  | 2846 3390 03 38N   | AXLE SEAT LH                      | 1    |
| 6        | 31AR136C01  | 2846 3390 02 92N   | AXLE SEAT RH                      | 1    |
| 7        | 24AL028C01  | 2846 3390 02 83N   | BEAM ASSEMBLY LH                  | 2    |
| 8        | 24AR028C01  | 2846 3390 02 94N   | BEAM ASSEMBLY RH                  | 2    |
| 9        | 95CX217C01  | 2846 3390 99 31  | WEAR PAD                          | 16   |
| 10       | 41CX008C01  | 2846 3390 9934 OR<br>2846 3390 99 56 OR<br>2846 3390 99 58 | LIFT AIR SPRING                   | 2    |
| 11       | 41CX014Z00  | 2846 3390 99 72N OR<br>2846 3390 99 73N                    | MAIN AIR SPRING                   | 2    |
| 12       | 44AX007Z00  | 2846 3390 99 37 OR<br>2846 3390 99 53                      | STABILIZER<br>(STEERING DAMPER)   | 2    |
| 13       | 11AL045Z00  | 5043 3390 01 23  | AIR SPRING MTG LH                 | 1    |
| 14       | 11AR045Z00  | 5043 3390 01 22N   | AIR SPRING MTG RH                 | 1    |
| 15       | 32AL011Z00  | 2846 3390 02 97N   | EXTERNAL BUMP STOP<br>ASSEMBLY LH | 1    |
| 16       | 32AR011Z00  | 2846 3390 02 98N   | EXTERNAL BUMP STOP<br>ASSEMBLY RH | 1    |
| 17       | 86CX049Z00  | 5043 3390 77 01  | REBOUND STRAP                     | 2    |
| 18       | 32CX031Z00  | 5043 3390 33 07  | REBOUND CLIP FINISHED             | 4    |

\* BOM FOR BEAM ASSEMBLY LH (24AL028C01)


Table 14.4a

| PART NUMBER | TML PART NUMBER  | DESCRIPTION                  | QTY |
|-------------|------------------|------------------------------|-----|
| 24AL028C01  |                  |                              |     |
| 24AL025C01  | 2846 3390 03 47N | BEAM ASSEMBLY<br>WELDMENT LH | 1   |
| 86CX037C01  | 2846 3390 34 09  | BUSH OUTER RUBBER            | 2   |
| 86CX038C01  | 2846 3390 34 11N | BUSHING INNER STEEL          | 2   |

\* BOM FOR BEAM ASSEMBLY RH (24AR028C01)

Table 14.4b

| PART NUMBER | TML PART NUMBER  | DESCRIPTION                  | QTY |
|-------------|------------------|------------------------------|-----|
| 24AR028C01  |                  |                              |     |
| 24AR025C01  | 2846 3390 03 48N | BEAM ASSEMBLY<br>WELDMENT RH | 1   |
| 86CX037C01  | 2846 3390 34 09  | BUSH OUTER RUBBER            | 2   |
| 86CX038C01  | 2846 3390 34 11N | BUSHING INNER STEEL          | 2   |



Scope of Supply - THSL

Table 14.5

| ITEM NO. | PART NUMBER | TML PART NUMBER | DESCRIPTION   | QTY. |
|----------|-------------|-----------------|---|------|
| 19       | 93CX007C01  | 2846 3390 3359N | M20 x 1.5 (CLASS 10, FLANGE HEX HEAD NUT)   | 2    |
| 20       | 90CX010C01  | 2846 3390 3363N | M16 x 2 x 60LG GRD. 10.9 FLANGE HD. BOLT  | 8    |
| 21       | 92CX102C01  | 2846 3390 3357N | M16 x 2 (GRD 10.0 ALL METAL PREVAILING TORQUE NUT)  | 12   |
| 22       | 90CX034C01  | 2846 3390 3362N | M10 x 1.5 x 25 LG (GRD. 8.8 FLANGE HD. BOLT) OR M10 x 1.5 x 25 LG (GRD. 10.9 FLANGE HD. BOLT) | 4    |
| 23       | 91CX129C01  | 5039 3390 3367N | M27x3x200LG GRD 10.9 HEX HD BOLT  | 4    |
| 24       | 91CX130C01  | 5039 3390 3368N | M27x3x210LG GRD 10.9 HEX HD BOLT  | 4    |
| 25       | 92CX113C01  | 5039 3390 3361N | M27 x 3 (GRD 10.0 HEX NUT)  | 8    |
| 26       | 94CX101C01  | 5039 3390 3315N | M27 HARDENED WASHER   | 16   |
| 27       | 94CX104C01  | 2846 3390 3312N | M16 HARDENED WASHER   | 16   |
| 49       | 91CX128C01  | 11064016620N    | M16X2.0X70Lg GRD 10.9 HEX HD BOLT   | 4    |

Scope of Supply - TML

Table 14.6

| ITEM NO. | TML PART NUMBER  | DESCRIPTION                                | QTY. |
|----------|------------------|--|------|
| 28       | 2846 3390 3318N  | M20 HARDENED PLAIN WASHER                  | 8    |
| 29       | 12460501057N     | BRIGHT WASHER 10.5 IS2016 ST SS8451-8C     | 4    |
| 30       | 2846 3390 3363N  | M16X2.0X80 LG.-FLANGE BOLT -10.9           | 8    |
| 31       | 5011 3240 65 03N | HEX FLANGE NUT (SELF LOCKING) M16X2 10.9 2 | 6    |
| 32       | 5011 3240 32 17  | M16 x 2 x 90LG GRD. 10.9 FLANGE HD. BOLT   | 18   |
| 33       | 2846 3390 3362N  | M10X1.5X25 LG.-FLANGE BOLT -10.9           | 4    |
| 34       | 2846 3390 3364N  | M18X2.5X130 LG.-FLANGE BOLT -10.9          | 2    |
| 35       | 5009 3240 32 05N | HEX FL BOLT M18X2.5X100                    | 2    |
| 36       | 2846 3390 3358   | M18X2.5-AMPT NUT-10                        | 4    |
| 37       | 2846 3390 3335N  | M18-HARDENED PLAIN WASHER                  | 4    |
| 38       | 1107 1712 551N   | HEX FL BOLT M12X55TS17130 10.9SS8451-8CH   | 2    |
| 39       | 11071510559N     | HEX FL BOLT M10X55 TS17130-8.8-SS8451S2-Y  | 4    |
| 40       | 2846 3390 3360N  | M20X2.5-AMPT NUT-10                        | 8    |
| 41       | 12051598073N     | HEX NUT M10 IS1364P3-8-SS8451-8C           | 4    |
| 42       | 2846 3390 3356N  | M12X1.75 - FLANGE HEX NUT-10               | 2    |
| 43       | 2846 3390 3365   | M20X2.5X75 LG.-FLANGE BOLT -10.9           | 8    |
| 44       | 2846 3390 3359N  | M20X1.5-FLANGE HEX NUT-10                  | 2    |
| 45       | 1214 340 1209N   | HEX FL NUT M12X1.5 ISO 12126 10 SS8451-8CH | 2    |
| 46       | 5006 3240 3213N  | HEX FL BOLT M16X2X70                       | 4    |
| 47       | 2846 3390 3312N  | M16 HARDENED PLAIN WASHER                  | 4    |
| 48       | 2846 3390 3357N  | M16X2-AMPT NUT-10                          | 4    |

---

## **TATA AUTOCOMP HENDRICKSON SUSPENSIONS PVT LTD**

Gat No. 431/1, Medankarwadi, Chakan - Alandi Road, Off. Pune - Nashik Highway,  
Near Hotel Gandharwa, PUNE - 410 501 | Tel:+91 2135 670670 | Email: [service@tacohendrickson.com](mailto:service@tacohendrickson.com)